



## Silver Center Room 703 Equipment Instructions

### To power on projector:

1. press *display power*, hold for two seconds, release
2. projector needs 30 seconds to power on

### Display computer image:

1. press *computer* on switcher
2. connect VGA cable from podium to laptop
3. power on laptop
4. if the image DOES NOT appear on screen:
  - a. **PC USERS-**  
depress “FN” key and  
LCD/CRT key together once  
or twice
  - b. **MAC USERS-**  
open apple menu, select  
*control panel* click *monitors*  
then *arrange* icon. Drag  
monitor icon onto the other

### To display image from DVD:

1. turn on DVD
2. press *DVD* on switcher
3. image will display
4. DVD volume control on switcher

### To display image from VCR:

1. turn on VCR
2. press *VCR* on switcher
3. image will display
4. VCR volume control on switcher

### To play a CD:

1. turn on DVD player
2. press *CD* on switcher
3. projector should remain **OFF** when using CD play back.

### Using Wireless LAV microphone:

1. power wireless lav unit
2. make sure *MUTE/ON* switch is **ON**
3. volume control labeled on rack mixer

### To power off projector:

1. press *display power*, hold for two seconds, release
2. projector needs 30 seconds to power off

TURN OFF THE PROJECTOR AT THE CONCLUSION OF YOUR CLASS

**Call Campus Media x82655 for assistance.**