



## Silver Center Rooms

505, 507, 512, 518, 520, 621,  
704,705, 711, 712, 718, 721, 801,  
802, 803, 809, 820

## Equipment Instructions

### To Power on projector:

1. press **ON** button and release

### To display a computer image:

1. press *laptop* on wall switcher
2. connect VGA cable from laptop to wall mounted switcher
3. power on laptop
4. volume control on wall switcher
5. if the image DOES NOT appear on the screen:

a. **PC USERS-**  
depress "FN" key and  
LCD/CRT key together  
once or twice

b. **MAC USERS-**  
open apple menu, select  
*control panel*, click *monitors*  
icon, then *arrange* icon.  
Overlap monitor icons.

### To display image from DVD/VCR:

1. turn on DVD/VCR player
2. press *video* on wall switcher
3. image will display
4. volume control on wall switcher

### To Power off projector:

1. press **OFF** button and release

TURN OFF THE PROJECTOR AT THE CONCLUSION OF YOUR CLASS.

call x82655 for assistance